



METO®
Basic S




METO®
Basic M



METO®
your retail label expert

STEP 1
Open the label cover and
slide in the label roll.



STEP 2
Press the knob left and
right side to open baseplate.



STEP 3
Pull out appr. 20cm of the
label roll. Close baseplate till
it snaps in.



STEP 4
Feed in the labels into the
top of the transport unit.



STEP 5
Press the handle several
times until the label tape
becomes visible at the end of
the transport plate.




Find your language on
meto.com/hls/support
Visit us on Youtube



METO[®]
Basic S



METO[®]
Basic M



METO[®]
Basic S



STEP 1
Push to open the
ink roller cover.




STEP 2
Remove ink roller.



STEP 3
Insert new ink roller
and close the cover.

METO[®]
Basic M



STEP 1
Push to open the
ink roller cover.



STEP 2
Remove ink roller.



STEP 3
Insert new ink roller
and close the cover.



www.meto.com
Visit us on
Youtube